


# CENTER® 200

CE



## Instruction Manual



### MINI AC CLAMP METER

# CONTENTS

<i>TITLE</i>	<i>PAGE</i>
<b>I. Safety Information</b> .....	1
Environmental Conditions.....	1
Explanation of Symbols.....	1
<b>II. Specification</b> .....	2
General Specification.....	2
Electrical Specification.....	3
<b>III. Instrument Familiarization</b> .....	4
Symbol Definition.....	5
<b>IV. Measuring Instruction</b> .....	6
4.1 ACV measurement.....	6
4.2 ACV measurement.....	7
4.3 DCV measurement.....	8
4.4 Resistance measurement.....	9
4.5 Continuity Test.....	10
4.6 Frequency measurement from the terminals.....	11
4.7 Frequency measurement with the clamp.....	12
<b>V. Battery Changing</b> .....	13
<b>VI. Maintenance</b> .....	14

## I. Safety Information

Do not operate the tester if the body of meter or the test lead look broken.

Check the main function dial and make sure it is at the correct position before each measurement.

Do not perform resistance and continuity test on a live power system.

Do not apply voltage between the test terminals and test terminal to ground that exceed the maximum limit record in this manual.

Exercise extreme caution when measuring live system with voltage greater than 60V DC or 30V AC.

Keep the fingers after the protection ring when measuring through the test lead.

Change the battery when the  symbol appears to avoid incorrect data.

### **Environmental Conditions:**

Altitude up to 2000 meters.

Operating temperature: 0°C ~ 40°C, <80% RH, non-condensing

Storage temperature: -10°C ~ 60°C, <70% RH, battery removed

Pollution Degree: 2

Installation Categories II

### **Explanation of Symbols:**

 Attention! Refer to operation Instructions.

 Dangerous voltage may be present at terminals.

 This instrument has double insulation.

**Approvals:**  EN61010 600V CAT II 300V CAT III

## II. Specification

### **General Specification:**

#### **Digital Display:**

3 3/4 digits LCD display with maximum reading 3999

#### **Analog Display:**

42 segments fast analog bar display

#### **Symbol and Scale range:**

adjust automatically according range and input signal

#### **Polarity:**

When negative signal is apply to the tester,  will show.

#### **Over Load:**

When the signal larger than the maximum will be show 

#### **Sample Rate:**

2 times/sec for digital data

20 times/sec for analog bar

#### **Low Power Indication:**

When the battery is under the proper operation range,  will appear on the LCD display.

**Power Source:** UM-4 or AAA 1.5V battery x 2.

#### **Auto Power Off:**

If there is no key or dial operation for 30 minutes, the meter will power itself off to save battery consumption.

**Clamp opening size:** 25mm

#### **Dimension (L x W x H) :**

193 x 50 x 28mm, 7.60 x 1.97 x1.1 inch

**Weight:** 230g, 8.11OZ ( include battery)

#### **Accessory:**

Instruction Manual, Leather Case, Test lead, Battery 1.5Vx2

**Battery Life:** 250 hr approx. (alkaline battery)

---

## **Electrical Specification:**

---

The accuracy specification is defined as  $\pm(\dots\%\text{reading} + \dots\%\text{count})$   
At  $23\pm 5^\circ\text{C}$ ,  $\leq 80\%\text{RH}$

### **DCV (Autorange)**

Range	Resolution	Accuracy	Input Impedance	Overload Protection
400V	0.1V	1%+2	1MΩ	660Vrms
600V	1V			

### **ACV (Autorange)**

Range	Resolution	Accuracy	Input Impedance	Overload Protection
		50Hz~500Hz		
400V	0.1V	1.5%+5	1MΩ	660Vrms
600V	1V			

### **ACA (Autorange)**

Range	Resolution	Accuracy		Overload Protection
40A	0.01A	50Hz~60Hz	60Hz~500Hz	600Arms
400A	0.1A	1.9%+5	2.5%+5	

### **Ohm ( Ω )**

Range	Resolution	Accuracy	MAX Test Voltage	Overload Protection
400Ω	0.1Ω	1%+2	1.5VDC	600Vrms


### **Continuity (•••)**

Range	Active Region	MAX Test Voltage	Overload Protection
•••	<40 Ohm	1.5 VDC	600Vrms

### **Frequency (Hz) (Autorange)**

Function	Range	Resolution	Accuracy	Sensitivity	Overload Protection
Current Frequency	20Hz - 4KHz	1Hz	0.1%+1	2Arms	600Arms
	10KHz	10Hz			
Voltage Frequency	10Hz-4KHz	1Hz	0.1%+1	3Vrms	600Vrms
	40KHz	10Hz			
	400KHz	100Hz			
	1MHz	1KHz			

### III. Instrument Familiarization:



- ① Current Sensing Clamp
- ② Safety protection ring
- ③ Clamp opening handle
- ④ Function select dial
- ⑤ LCD display
- ⑥ COM input terminal
- ⑦ Positive input terminal
- ⑧ Data hold button
- ⑨ Battery cabinet

---

## Symbol Definition:

---



	Low battery indication
<b>AUTO</b>	Auto range indication
	Manual range indication
	Hold Data indication
	Continuity function indication
<b>V</b>	Voltage measurement indication
<b>A</b>	Current measurement indication
	Alternative source indication
	Direct source indication
	Polarity indication
	Analog bar graph indication
<b>MK Hz</b>	Frequency Measurement indication

## IV. Measuring Instruction:

### 4.1 ACA measurement:

Switch the main function selector to **A  $\sim$**  range.

Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw.

Close the clamp and get the reading from the LCD panel.



**Note:**

Before this measurement, disconnect the test lead with the meter for safety.

In some occasion that the reading is hard to read, push the HOLD button and read the result later.



**CORRECT**



**INCORRECT**


#### 4.2 ACV measurement:

Switch the main function selector to **V  $\sim$**  range.

Connect red test lead to “+” terminal and black one to the “ COM “ terminal.

Measure the voltage by touch the test lead tips to the test circuit where the value of voltage is needed.

Read the result from the LCD panel.




#### 4.3 DCV measurement:

Switch the main function selector to **V** --- range.

Connect red test lead to “+” terminal and black one to the “ COM “ terminal.

Measure the voltage by touch the test lead tips to the test circuit where the value of voltage is needed.

Read the result from the LCD panel.



#### 4.4 Resistance measurement:

Switch the main function to  $\Omega$  range.


Connect red test lead to “+” terminal and black one to the “ COM ” terminal.

Connect tip of the test leads to the points where the value of the resistance is needed.

Read the result from the LCD panel.

**Note:**

When take resistance value from a circuit system, make sure the power is cut off and all capacitors need to be discharged.




#### 4.5 Continuity Test:

Switch the main function to  $\text{Ω}$  range.

Connect red test lead to “+” terminal and black one to the “ COM ” terminal.

Connect tip of the test leads to the points where the conduction condition needed.

If the resistance is under  $40\text{Ω}$  , the beeper will sound continuously.



> Short circuit

> Open circuit

#### 4.6 Frequency measurement from the terminals:


Switch the main function to “ Hz ” range.

Connect red test lead to “ + ” terminal and black one to the “ COM ” terminal.

Connect tip of the test leads to the points where the value of the resistance is needed.

Connect tip of the test leads to the points where the frequency of the voltage signal is needed.

Read the Result from the LCD panel.



#### 4.7 Frequency measurement with the clamp:


Switch the main function selector to “ Hz ” range.

Open the clamp by pressing the clamp-opening handle and insert the cable to be measured into the clamp.

Close the clamp and get the reading from the LCD panel.


**Note:**

When doing frequency measurement, user should either use the terminal signal or clamp signal but not both. If both sources are applied an error will occur.



## V. Battery Changing:

1. When the battery voltage drop below proper operation range the  symbol will appear on the LCD display and the battery need to changed.
2. Before changing the battery, switch the main dial to "OFF" and disconnect test leads.  
Open the cover of the battery cabinet by a screwdriver.  
Replace the old batteries with two UM-4 or AAA size batteries.
3. Close the battery cabinets cover and fasten the screw.



## **VI. Maintenance:**

---

### **⚠ WARNING!**

---

Before open the battery door, disconnect both test lead and never uses the meter before the battery door is closed.

---

### **CAUTION**

---

To avoid contamination or static damage, do not touch the circuit board without proper static protection.

---

### **REMARK**

---

- \* If the meter is not going to be used for a long time, take out the battery and do not store the meter in high temperature or high humidity environment.
- \* When take current measurement, keep the cable at the center of the clamp will get more accurate test result.
- \* Repairs or servicing not covered in this manual should only by qualified personal.

---

### **CLEANING**

---

Periodically wipe the case with a dry cloth and detergent. Do not use abrasives or solvents on this instrument.



Authorized Distributor  
APL ASIA CO., LTD.

11/129-132 Moo.5 Lamlukka Rd., T.Kookut, A.Lamlukka, Pathumthani 12130 Thailand.  
TEL. 0-2995-4461-3, FAX. 0-2995-4464  
[www.apl-asia.com](http://www.apl-asia.com)  
EMAIL : [sales@apl-asia.com](mailto:sales@apl-asia.com)  
LINE@ : @APL-ASIA

---

## **CENTER® CENTER TECHNOLOGY CORP.**

4 / F NO. 415, Jung-Jeng Rd., 238 Shu-Lin, Taipei, Taiwan  
TEL : 886-2-26763926      E-Mail : [center@centertek.com](mailto:center@centertek.com)  
FAX : 886-2-26763925      <http://www.centertek.com>

**200-02**

---

---