

Temperature Data Logger User Manual



1 Product introduction

This device is a simple and portable LCD screen temperature data logger. This product is mainly used to monitor and record the temperature data during transportation and storage. It's widely used in all aspects of warehouse, cold chain logistics, such as refrigerated containers, refrigerated trucks, refrigerated distribution boxes and cold storage laboratories. It's easy to read data and configure parameters through the USB interface, and the data report can be easily and automatically generated and obtained without any extra drivers to be installed in computer.

2 Technical parameters

| Item | Parameters |
|--------------------|---|
| Temperature Scale | °C or °F [Default: °C] |
| Measuring Range | Temp -30°C ~ +70°C |
| Accuracy | ±0.3°C |
| Resolution | 0.1°C |
| Data Capacity | 34560pcs |
| Usage Type | Multiple times |
| Start Mode | Button Start or Timed Start [Default: Button Start] |
| Recording Interval | 10 seconds to 99 hours adjustable [Default: 10 minutes] |
| Start Delay | Programmable (0~72 hours) [Default: 30 minutes] |
| Alarm Range | Programmable high or low alarm limit for each channel [Default: <2°C or >8°C] |
| Alarm Type | Single type, Cumulative type |
| Alarm Delay | Programmable (0~99 hours) [Default: 10 minutes] |
| Form of Report | PDF report and CSV file are optional [Default: PDF and CSV] |
| Interface | USB2.0 Interface |
| Waterproof | IP65 |
| Product Size | 100mm*43mm*12mm |
| Product Weight | 54g |
| Battery Shelf Life | 2 years (Normal temperature 25°C) |
| Time Zone | Programmable [Default: UTC +0:00] |

3 Operating instructions

1) Start recording

Long press the start button more than 3s until the "▶" or the "WAIT" symbol appears on the screen, indicating that the device has successfully started recording.

2) Stop recording


Long press the stop button more than 3s until the "■" symbol appears on the screen, indicating that the device stops recording.

3) Get report

After recording, connect the device with USB port of PC, it will automatically generate PDF and CSV report, click open to view the data report.

Note: If the logger is stopped during the status of start delay, there will be a PDF Report but no data.

4 LCD display description



| | | | |
|---------|--|----|----------------------|
| 1 | √ Normal × Alarm | 6 | Battery power |
| 2 | ▶ In recording status ■ Stop recording status | 8 | Interface indication |
| 3 and 7 | Alarm area: ↑ H1 H2 (high temperature alarm) ↓ L1 L2 (low temperature alarm) | 9 | Temperature value |
| 4 | Start delay status | 10 | Temperature unit |
| 5 | Button stop mode invalid | | |

Short press the start button to switch the display interface in turn

Real time temperature interface → Log interface → Mark number interface → Temperature maximum interface → Temperature minimum interface.



① Real time temperature interface (initialization status)



② Log interface (record status)



③ Mark number interface (record status)



④ Temperature max interface (record status)



⑤ Temperature minimum interface
(record status)

5 LED indicator description


| Button | Indicator light | Status |
|---|--|-----------------|
| Press and hold the start button for 3 seconds for the first time. | The green light is lighting for 3 seconds. | Start Recording |
| After turning on, press and hold the stop button for 3 seconds. | The red light is lighting for 3 seconds. | Stop Recording |

| Status | Operating | Indicator status |
|-------------|------------------------|--|
| Inactivated | Short press the button | The green light (normal) and the red light (alarm) will flash simultaneously. |
| Activated | | <p>LED will flash every 10 seconds automatically during the recording process.</p> <p>If it's green light flashing every 10 seconds, it means temperature is not over limit.</p> <p>If it's red light flashing every 10 seconds, it means temperature is over limit.</p> <p>Note: As long as over-temperature is found during the recording process, the green light will no longer flash.</p> |
| Stopped | No button press | The green light and red light won't flash. |
| | Short press the button | <p>The green light flashes, indicating no over-temperature during the recording process.</p> <p>The red light flashes, indicating over-temperature during the recording process.</p> |

6 Description of battery status display

| Battery status display | Capacity |
|---|------------|
|  | 40% ~ 100% |
|  | 15% ~ 40% |
|  | 5% ~ 15% |
|  | <5% |

7 Battery replacement



Step 1: Turn the battery cover counter clockwise to open it.

Step 2: Take off the battery cover.

Step 3: Remove the battery.

Step 4: Replace the battery.

(Please note the positive and negative terminals.)

Step 5: Please install the battery cover.

Step 6: Turn the battery cover clockwise to close it.

Note:

It is recommended to check the battery status before restarting the device to ensure that the remaining battery power could finish the recording.

8 Management software download

Download address of the management software for parameters configuration:

<http://d.tzonedigital.com/TM.aspx>

9 Notes

1. For the first time use, please connect the device to computer for parameter configuration to synchronize the system time.
2. After reconfiguration, the previously recorded data will be cleared. Please read and save the historical data before configuring the device parameters.
3. If there is no button operation for one minute, the device will automatically turn off the screen. Click the button to light up the screen again.
4. Please do not remove the battery during the device recording.
5. When the power status is not 100%, do not use it for long-distance transportation.
6. In the initialization/stop recording status, the display may show "RE-CF" after replacing the battery. Please save the device parameters again, otherwise the time may be wrong.



Authorized Distributor
APL ASIA CO., LTD.
11/129-132 Moo.5 Lamlukka Rd., T.Kookut, A.Lamlukka, Pathumthani 12130
Thailand. TEL. 0-2995-4461-3, FAX. 0-2995-4464
www.apl-asia.com
EMAIL : sales@apl-asia.com
LINE@ : @APL-ASIA