

Operation Manual

10cm Vane Air Flow Meter (Optional Airflow cone available)



Model: ■ 8916
■ 8917
■ 8919



INTRODUCTION

Thank you for purchasing this air flow meter. This meter is specially designed for HVAC&R application that combines those required measurements, like Air velocity, Air volume, Temp., RH, WBT, DP, and CO2 in one handy meter.

The Air flow cone compatibility also helps in quick volume measurement. Users can be freed from the hassle of calculating dimensions.

Features :

- **Measures** air velocity, air volume, temp., RH, WBT, DP, and CO2.
- **Big LCD** digital display
- **Multi-points** and **Timed** average
- **Metric& Imperial** units selectable
- Round & Square **airflow cone** compatible
- **Fast** response & **Accurate** reading
- **Dew Point** calculated in seconds
- **Wet Bulb** calculated in seconds
- **Low** battery indication
- Blue **back light** for dark places use
- **Handheld size**, easy to carry

Function Table

	8916	8917	8919
Air Velocity	●	●	●
Air volume	●	●	●
Air temp.	●	●	●
Humidity		●	●
Dew Point		●	●
Wet Bulb		●	●
CO2			●

MATERIAL SUPPLIED

This package contains:


- ✓ The meter x 1
- ✓ Battery x 4 (AAA size)
- ✓ Operation manual x1
- ✓ Hard carry case x1

Optional accessory:

- ✓ Airflow cone set:
Round conex1 (dia.210mm)
Square conex1 (346x346mm)

CONTROLS AND INDICATORS

LCD DISPLAY



Upper display: air velocity, RH, CO2 value
duration time in average.

Lower display: temp., air volume readings.

HOLD : freezes the current reading.

MAX MIN: maximum and minimum reading

●🕒 **AVG**: multi-points mean & timed average

🔋 : battery low voltage indicator

ppm : CO2 unit

m/s, fpm: air velocity unit

%RH : relative humidity

°C °F : temperature units

CMM, CFM: air volume units


WBT, DP : wet bulb, dew point temp.

inch² cm² : area dimension units

🔊 : air flow cone indicator

✱ : vain icon in this meter

KEY PAD



-  - Turns the meter on and off.
 - Long press to go in and out setup mode.
-  - Freezes current reading on LCD
 - Long press to review MIN and MAX
 - In average mode, press to record data or start timed recording.
 - In setup mode, press to enter data settings.
-  - Switches upper display.
 - Long press to go into average mode.
 - In average mode, press to average and return to normal mode.
 - In setup mode, press to select category or increase value.
-  - Switches lower display.
 - In average mode, press to view recorded and average reading of all parameters.
 - In setup mode, press to select category or decrease value.
-  +  - Disables auto power off.

MEASUREMENT

POWER ON/OFF

Press  to turn on the meter. The screen shows full display with blue backlight on and enter normal mode. (Model 8916/8917). For model 8919, it proceeds 30 seconds warm up when turned on, then goes into normal mode. Press  again in any mode to turn off the meter.

The meter is preset auto sleep in 20 minutes of inactivity. To disable this function, hold down  and  for 2 seconds to turn on the meter while it is off. It shows "n" on the LCD (see Fig.A) and goes into normal mode (or 30 sec. warm up for model 8919) and won't turn off itself until  is pressed or out of voltage.



Fig.A

SWITCH DISPLAY

When the meter is turned on, it shows the current readings of **air velocity** on the upper display and **air temp.** on the lower (see Fig.B). To switch display of other measurements, press  or .



Fig.B

Short press , the upper display will cycle among **air velocity**, **RH**, and **CO2** (8919 only).

And short press , the lower display cycles among **air temp.** → **air volume** → **WBT**(wet bulb temp) → **DP**(dew point temp)(Fig.C).



Fig.C

AIR VOLUME

To measure air volume, it is necessary to get the outlet dimensions. Go to Setup mode and input the AREA value first before taking measurement. (See page 9 , P2.0)

After AREA setting is completed, press  to switch the display to air volume and the measured air volume will be displayed on the lower LCD.

Measure with airflow cones

Two airflow cones are available for using with this anemometer and are sold as a set.

■ Square
346x346mm


■ Round
dia. 210mm



To measure air volume with use of an airflow cone. Just plug on the cone and the meter will automatically recognize it and shows a  on the display(Fig.C). Then the meter will calculate the air volume by the default dimensions despite of any AREA value is input.

Note:

Be sure the airflow cone is well mounted and locked tight. (See pic.1)



RH(8917/8919 only)

The capacitive humidity sensor is built in the center of the vane to measure air flow relative humidity and is used for calculating dew point and wet bulb temperatures.

Press  to switch to RH display. It shows measured RH readings on the upper display. And it is also possible to display with RH offset. Go to Setup mode (see page 9, P3.0) and input offset value, then the displayed readings will be the measured data with offset.

CO2 (8919 only)

Model 8919 features additional CO2 measurement for HVAC application. The NDIR CO2 sensor is built in the rear side of the meter. Press  to switch to CO2 display and the current reading will show on the upper LCD.

For places in high altitude, the pressure compensation needs to be considered in order to get accurate CO2 readings. Go to Setup mode P4.0 and input the pressure value according to your location before taking measurements.

DATA HOLD

In normal mode, press  and the current readings are fixed on the LCD with **HOLD** icon on the top and won't change until a second press on .

MIN/MAX

In normal mode, long press  for 3 seconds and it displays the minimum readings of all parameters since power on with **MIN** icon on the top. Long press this button again, it shows the maximum readings with **MAX** on the top. (Fig.D) Long press again and it returns to the normal mode.

While reviewing the minimum and maximum data, press  and  and it switches to display MIN and MAX readings of other parameters.



Fig.D

AVERAGE

This meter calculates multi-points mean and timed average of all parameters.

Multi-points average

In normal mode, press  for 2 seconds to enter multi-point average mode. (See Fig.E, the upper display shows the record number and the lower is the measured reading)

- Press  to record readings.
- Press  to see the multi-point mean once all data is recorded. It shows the average readings with flashing "● AVG".
- Press  to view the average reading of each parameter.

(See Fig.F, the upper display means total 20 recorded data; and the lower display is the average reading of RH.)

- Press  to return to normal mode.



Fig.E



Fig.F

Timed average

In normal mode, press  for 2 seconds and it goes into multi-point average. Press it again to enter timed average mode. (See Fig.G, the upper display shows the duration time in **second**, the maximum time is 19999 seconds, and the lower is the measured reading)

- Press  to start recording, the upper display starts the counting clock.
- Press  to stop and calculate the timed average. It shows the duration seconds on the upper display and the average readings at the lower display with flashing "●AVG". (See Fig.H)



Fig.G



Fig.H

- Press  to view average reading of other parameters.
- Press  to return to normal mode.

SETUP

The setup mode is for those related parameters setting that can ensure more accurate measurements.

It includes:

P1.0: Unit selection

P2.0: AREA size

P3.0: RH offset

P4.0: Pressure input (*model 8919 only*)

In normal mode, press  for 2 seconds to enter SETUP mode. It starts with P1.0 unit selection. Press  or  to select among P1.0 to P4.0. Long press  again to return to normal mode.

P1.0: Unit selection

In P1.0 (Fig.I), press  to enter units selection (Fig.J). Then press  or  to switch from Metric to Imperial unit.

The units include air velocity(m/s, fpm), temp.(C, F), air volume(cmm,cfm), and area size(cm²,inch²). After finishing the setting, press  to return to P1.0.



Fig.I



Fig.J

P2.0: AREA Size

In P2.0(Fig.K), press  to enter AREA size setting. It shows "99999" on the lower display with the first digit flashing. (Fig.L) The flashing digit means it is ready to adjust. Press  to change the number and it will cycle from 0 to 9. Press  to move to next digit. After completed, press  again to return to P2.0.



Fig.K



Fig.L

P3.0: RH offset

In P3.0(Fig.M), press  to enter RH offset setting. It shows blinking 0.0 RH reading on the upper display(Fig.N). Press  to increase the offset value and  to decrease it. When finished the setting, press  again to return to P3.0.



Fig.M



Fig.N

P4.0:Pressure input (8919 only)

In P4.0 (Fig.O), press  to enter pressure input. It shows default 1013 hpa on the display with blinking value at the upper (Fig.P). Press  to increase the pressure value and  to decrease it. Once finished, press  again to return to P3.0.



Fig.O



Fig.P

CALIBRATION

RH CALIBRATION

The humidity calibration of this meter requires specific fixture and cannot be done by end users. Please contact the dealer for calibration service.

CO₂ CALIBRATION

The meter is calibrated at standard 400ppm CO₂ concentration in factory. It's suggested to do manual calibration regularly to maintain good accuracy.

Note:

When the accuracy becomes a concern after a long time use, return to dealers for standard calibration.

400ppm calibration

400ppm calibration is suggested to be done in outdoor fresh air that is well ventilated and in sunny weather.

CAUTION:

Do not calibrate the meter in the air with unknown CO₂ concentration. Otherwise, it will be calibrated as default 400ppm and leads to inaccurate measurements.

Place the meter in the **calibration site** and follow the below procedure to complete the 400ppm calibration.

1. While the meter is turned off, hold down , , and  simultaneously to enter CO2 calibration mode. It runs 30 seconds countdown with CAL at lower display (Fig.T), and then starts 400ppm calibration.
2. During calibration, a CO2 reading in the range of 380 to 420ppm will be flashing on the upper display. (Fig.U)
3. Wait for 10 minutes until the reading stops flashing, the 400ppm calibration is completed and it returns to normal mode automatically. .
To abort the calibration, turn off the meter at any time.



Fig.T



Fig.U

NOTE:

Be sure the batteries are with full voltage during the calibration to prevent from interruption and fail in the calibration.

LOW-BATTERY

When the battery voltage falls below the measurement required range,  shows on the LCD. Replace with fresh batteries to ensure accurate measurements.

TROUBLESHOOTING

1. Power on but no display

- 1) Make sure the time of pressing  key is more than 200mS.
- 2) Check the batteries are in good contact with correct polarity.
- 3) Replace new batteries and try again.

2. Display disappeared

Check whether the low battery indicator shows before display disappears, if yes, replace with new batteries.

3. Error code and solution

1) **Air Temp.**

E02: Temp. is under low range limit.
Put the meter in room temp for 30 minutes. If E02 still shows, send to the dealer for repair.

E03: Temp. is over high range limit.
Put the meter in room temp for 30 minutes. If E03 still shows, send to the dealer for repair.

E31: temperature measuring AD damaged. Send to the dealer for repair.

2) **RH**

E04: temperature error caused the RH error. Check the temp. error solution.

E11: RH calibration error.
Try recalibration or send for repair if it still can't work.

E33: RH measurement circuit error.
Send to the dealer for repair.

3) DP and WBT

E04: Temp. or RH error.

Check temp. or RH error solution.

4) Air velocity

E03: Velocity is over high range limit.

Try in range measurement. If it still shows in range velocity, recalibrate it send for repair.

5) Air volume

E03: Reading exceeds display limit.

Check if the outlet area setting is correct.

E04: Air velocity error.

Try recalibration or send for repair if it still can't work.

6)CO2

E03: Temp. is over high range limit.

Put the meter in room temp. for 10 minutes and if E03 still shows, recalibrate it or send for repair.

E01/E33: Voltage too low or CO2 module error.

Check if battery low icon showed on the LCD, if yes, replace with new batteries.

Try recalibration, or send for repair if it still can't work.

7) Others

E32: Memory IC error.

Turn off the meter and turn it on again. If E32 still shows, send to the dealer for repair.

SPECIFICATION

	8916	8917	8919
Measuring range			
Air velocity		0.20~30.00m/s	
Air volume		0 to 99999 m ³ /m	
Temperature		-20.0~60.0°C (-5~140°F)	
Relative Humidity	N/A	0.1%~99.9%RH	
DP(Dew point temp.)	N/A	-5.0~59.9°C	
WBT(Wet bulb temp.)	N/A	-20.0~59.9°C	
CO2	N/A	N/A	0~9999 ppm, (5001~9999 ppm out of scale range)
Resolution			
	0.1m/s, 0.1(0~9999.9) or 1(10000~99999), 0.1°C/°F, 0.1%RH		
Accuracy			
Air velocity	+/- (1.5% of reading +0.3m/s) for under 20m/s +/- (3% of reading +0.3m/s) for above 20m/s		
Temperature	±0.6°C		
Relative Humidity	N/A	±3%RH(at 25°C, 10~90%RH); ±5%RH(others)	
CO2	N/A	N/A	±30ppm±5% of rdg.(0~5000ppm)
CO2 Warm-up time	N/A	N/A	30 seconds
Vane / Meter size (mm)	Dia. 100, 269(L)x106(W)x51(H)		
Air flow cone size(mm)			
Round	Dia. 210		
Square	346x346		
Operating condition (avoid condensation)			
	0 to 50 °C, <80%RH		
Storage condition			
	-10~ 50°C, <90%RH(avoid condensation)		
Power supply			
	AAA x 4pcs		
Standard package			
	Meter, manual ,AAA bat. , Hard carry case		
Optional accessory			
	Air flow cone set (w/soft carry case)		

WARRANTY

The meter is warranted to be free from defects in material and workmanship for a period of one year from the date of purchase. This warranty covers normal operation and does not cover battery, misuse, abuse, alteration, tampering, neglect, improper maintenance or damage resulting from leaking batteries.

Proof of purchase is required for warranty repairs. Warranty is void if the meter has been opened .

RETURN AUTHORIZATION

Authorization must be obtained from the supplier before returning items for any reason. When requiring a RA (Return Authorization) , please include data regarding the defective reason, the meters are returned along with good packing to prevent any damage in shipment and insured against possible damage or loss.

Accuracy, the Zenith of Measuring / Testing Instruments !

Hygrometer/Psychrometer

Thermometer

Anemometer

Sound Level Meter

Air Flow meter

Infrared Thermometer

K type Thermometer

K.J.T. type Thermometer

K.J.T.R.S.E. type Thermometer

pH Meter

Conductivity Meter

T.D.S. Meter

D.O. Meter

Indoor Air Quality Meter

Manometer

Tacho Meter

Data logger

Temp./RH datalogger

Wireless datalogger

More products available !



2021.02 v.02