

# DIGITAL THERMOMETER

## WT-1

### Parameters

- ◆ Temperature range:  $-50^{\circ}\text{C} \sim +300^{\circ}\text{C}$  ( $-58^{\circ}\text{F} \sim +572^{\circ}\text{F}$ )
- ◆ Distinguishing rate:  $0.1^{\circ}\text{C}$
- ◆ Accuracy:  $(-20^{\circ}\text{C} \sim 80^{\circ}\text{C}) \pm 1^{\circ}\text{C}$
- ◆ Power voltage: DC 1.5V

### Functions

- ◆ Memory of the last measuring
- ◆ Measuring and display low voltage
- ◆ Saving power: auto-off after 15 minutes of no-operation
- ◆ Sensor fault display
- ◆ Switch between  $^{\circ}\text{C}$  and  $^{\circ}\text{F}$

### Operation description

- ◆ [ON/OFF]: Press the key to turn on/off the thermometer. When turn on it displays the last measuring temperature for 1.5 second then enters into measuring mode. Auto-off after 15 minutes of no-operation.
- ◆ [ $^{\circ}\text{C}/^{\circ}\text{F}$ ]: In the mode of temperature display press the key to switch between  $^{\circ}\text{C}$  and  $^{\circ}\text{F}$ .
- ◆ Measuring and display low voltage: when voltage lower than 1.3V LCD displays "LOW".
- ◆ Display E00 when sensor open circuit or lower than measuring range; Display E11 when sensor short circuit or higher than measuring range.



Authorized Distributor  
API ASIA CO., LTD.

11/129-132 Moo.5 Lamluukka Rd., T.Kookut, A.Lamluukka, Pathumthani 12130 Thailand.  
TEL: 0-2995-4461-3, FAX: 0-2995-4464

www.api-asia.com

EMAIL: sales@api-asia.com

LINE@ : @APL-ASIA